

Model Viso Two

| <i>Function</i> | <i>Format</i> | <i>Address Hex</i> | <i>Data Hex</i> | <i>Address Dec</i> | <i>Data Dec</i> | <i>Comment</i> |
|------------------------|----------------------|-------------------------------|----------------------------|-------------------------------|----------------------------|-----------------------|
| AM/FM/DB | NEC | 856A | F9 | 34154 | 249 | |
| Audio Mode | NEC | 856A | 2D | 34154 | 45 | |
| Cab/Sat | NEC | 856A | 25 | 34154 | 37 | |
| Clear | NEC | 859A | 56 | 34202 | 86 | |
| Cursor Down | NEC | 859A | 5E | 34202 | 94 | |
| Cursor Left | NEC | 859A | 60 | 34202 | 96 | |
| Cursor Right | NEC | 859A | 5F | 34202 | 95 | |
| Cursor Up | NEC | 859A | 5D | 34202 | 93 | |
| Display | NEC | 859A | 5C | 34202 | 92 | |
| DVD | NEC | 859A | 0F | 34202 | 15 | |
| DVD Digit 0 | NEC | 859A | 52 | 34202 | 82 | |
| DVD Digit 1 | NEC | 859A | 49 | 34202 | 73 | |
| DVD Digit 2 | NEC | 859A | 4A | 34202 | 74 | |
| DVD Digit 3 | NEC | 859A | 4B | 34202 | 75 | |
| DVD Digit 4 | NEC | 859A | 4C | 34202 | 76 | |
| DVD Digit 5 | NEC | 859A | 4D | 34202 | 77 | |
| DVD Digit 6 | NEC | 859A | 4E | 34202 | 78 | |
| DVD Digit 7 | NEC | 859A | 4F | 34202 | 79 | |
| DVD Digit 8 | NEC | 859A | 50 | 34202 | 80 | |
| DVD Digit 9 | NEC | 859A | 51 | 34202 | 81 | |
| DVD Scan Backward | NEC | 859A | 48 | 34202 | 72 | |
| DVD Scan Forwad | NEC | 859A | 47 | 34202 | 71 | |
| DVD Skip Backward | NEC | 859A | 46 | 34202 | 70 | |
| DVD Skip Forward | NEC | 859A | 45 | 34202 | 69 | |
| DVD Slow Backward | NEC | 859A | 6A | 34202 | 106 | |
| DVD Slow Forward | NEC | 859A | 5B | 34202 | 91 | |
| Enter | NEC | 859A | 66 | 34202 | 102 | |
| Front | NEC | 856A | 27 | 34154 | 39 | |
| Info | NEC | 856A | 3F | 34154 | 63 | |
| iPod Cursor Down | NEC | 859A | 21 | 34202 | 33 | |
| iPod Cursor Left | NEC | 859A | 23 | 34202 | 35 | |
| iPod Cursor Right | NEC | 859A | 22 | 34202 | 34 | |
| iPod Cursor Up | NEC | 859A | 20 | 34202 | 32 | |
| iPod Display | NEC | 859A | 1C | 34202 | 28 | |
| iPod Enter | NEC | 859A | 37 | 34202 | 55 | |
| iPod Menu | NEC | 859A | 19 | 34202 | 25 | |
| iPod Pause | NEC | 859A | 13 | 34202 | 19 | |
| iPod Play | NEC | 859A | 11 | 34202 | 17 | |
| iPod Random | NEC | 859A | 1B | 34202 | 27 | |
| iPod Repeat | NEC | 859A | 1D | 34202 | 29 | |
| iPod Return | NEC | 859A | 1A | 34202 | 26 | |
| iPod Scan Backward | NEC | 859A | 15 | 34202 | 21 | |
| iPod Scan Forward | NEC | 859A | 14 | 34202 | 20 | |
| iPod Skip Backward | NEC | 859A | 17 | 34202 | 23 | |
| iPod Skip Forward | NEC | 859A | 16 | 34202 | 22 | |
| iPod Stop | NEC | 859A | 12 | 34202 | 18 | |

Model Viso Two

| <i>Function</i> | <i>Format</i> | <i>Address Hex</i> | <i>Data Hex</i> | <i>Address Dec</i> | <i>Data Dec</i> | <i>Comment</i> |
|------------------------|----------------------|-------------------------------|----------------------------|-------------------------------|----------------------------|-----------------------|
| Menu | NEC | 859A | 59 | 34202 | 89 | |
| Mute | NEC | 856A | 99 | 34154 | 153 | |
| Off | NEC | 856A | 94 | 34154 | 148 | |
| On | NEC | 856A | 93 | 34154 | 147 | |
| Open | NEC | 859A | 41 | 34202 | 65 | |
| Pause | NEC | 859A | 43 | 34202 | 67 | |
| Play | NEC | 859A | 42 | 34202 | 66 | |
| Preset Down | NEC | 856A | FA | 34154 | 250 | |
| Preset Up | NEC | 856A | 8F | 34154 | 143 | |
| Program | NEC | 859A | 55 | 34202 | 85 | |
| Random | NEC | 859A | 5A | 34202 | 90 | |
| Repeat | NEC | 859A | 57 | 34202 | 87 | |
| Return | NEC | 859A | 67 | 34202 | 103 | |
| Setup | NEC | 856A | 3E | 34154 | 62 | |
| Sleep | NEC | 856A | 9B | 34154 | 155 | |
| Stop | NEC | 859A | 44 | 34202 | 68 | |
| Sub Volume Down | NEC | 856A | 33 | 34154 | 51 | |
| Sub Volume Up | NEC | 856A | 32 | 34154 | 50 | |
| Title | NEC | 859A | 64 | 34202 | 100 | |
| Tune Down | NEC | 856A | EE | 34154 | 238 | |
| Tune Up | NEC | 856A | ED | 34154 | 237 | |
| Tuner Digit 0 | NEC | 856A | 89 | 34154 | 137 | |
| Tuner Digit 1 | NEC | 856A | 80 | 34154 | 128 | |
| Tuner Digit 2 | NEC | 856A | 81 | 34154 | 129 | |
| Tuner Digit 3 | NEC | 856A | 82 | 34154 | 130 | |
| Tuner Digit 4 | NEC | 856A | 83 | 34154 | 131 | |
| Tuner Digit 5 | NEC | 856A | 84 | 34154 | 132 | |
| Tuner Digit 6 | NEC | 856A | 85 | 34154 | 133 | |
| Tuner Digit 7 | NEC | 856A | 86 | 34154 | 134 | |
| Tuner Digit 8 | NEC | 856A | 87 | 34154 | 135 | |
| Tuner Digit 9 | NEC | 856A | 88 | 34154 | 136 | |
| Tuner Mode | NEC | 856A | 6A | 34154 | 106 | |
| VCR/MP | NEC | 856A | 26 | 34154 | 38 | |
| Volume Down | NEC | 856A | 9E | 34154 | 158 | |
| Volume Up | NEC | 856A | 9F | 34154 | 159 | |
| Zoom | NEC | 859A | 54 | 34202 | 84 | |