

Model Viso Five

<i>Function</i>	<i>Format</i>	<i>Address Hex</i>	<i>Data Hex</i>	<i>Address Dec</i>	<i>Data Dec</i>	<i>Comment</i>
AM/FM/DB	NEC	856A	F9	34154	249	
Cab/Sat	NEC	856A	25	34154	37	
Center Volume Down	NEC	856A	A1	34154	161	
Center Volume Up	NEC	856A	A0	34154	160	
Clear	NEC	859A	56	34202	86	
Cursor Down	NEC	859A	5E	34202	94	
Cursor Left	NEC	859A	60	34202	96	
Cursor Right	NEC	859A	5F	34202	95	
Cursor Up	NEC	859A	5D	34202	93	
Display	NEC	859A	5C	34202	92	
DVD	NEC	859A	0F	34202	15	
DVD Digit 0	NEC	859A	52	34202	82	
DVD Digit 1	NEC	859A	49	34202	73	
DVD Digit 2	NEC	859A	4A	34202	74	
DVD Digit 3	NEC	859A	4B	34202	75	
DVD Digit 4	NEC	859A	4C	34202	76	
DVD Digit 5	NEC	859A	4D	34202	77	
DVD Digit 6	NEC	859A	4E	34202	78	
DVD Digit 7	NEC	859A	4F	34202	79	
DVD Digit 8	NEC	859A	50	34202	80	
DVD Digit 9	NEC	859A	51	34202	81	
Enter	NEC	859A	66	34202	102	
Ext 7.1	NEC	856A	A4	34154	164	
Front	NEC	856A	27	34154	39	
Info	NEC	856A	3F	34154	63	
iPod Cursor Down	NEC	859A	21	34202	33	
iPod Cursor Left	NEC	859A	23	34202	35	
iPod Cursor Right	NEC	859A	22	34202	34	
iPod Cursor Up	NEC	859A	20	34202	32	
iPod Display	NEC	859A	1C	34202	28	
iPod Enter	NEC	859A	37	34202	55	
iPod Menu	NEC	859A	19	34202	25	
iPod Pause	NEC	859A	13	34202	19	
iPod Play	NEC	859A	11	34202	17	
iPod Random	NEC	859A	1B	34202	27	
iPod Repeat	NEC	859A	1D	34202	29	
iPod Return	NEC	859A	1A	34202	26	
iPod Scan Back	NEC	859A	17	34202	23	
iPod Scan Forward	NEC	859A	16	34202	22	
iPod Stop	NEC	859A	12	34202	18	
Menu	NEC	859A	59	34202	89	
Mute	NEC	856A	99	34154	153	
Off	NEC	856A	94	34154	148	
On	NEC	856A	93	34154	147	
Open	NEC	859A	41	34202	65	
Pause	NEC	859A	43	34202	67	

Model Viso Five

<i>Function</i>	<i>Format</i>	<i>Address Hex</i>	<i>Data Hex</i>	<i>Address Dec</i>	<i>Data Dec</i>	<i>Comment</i>
Play	NEC	859A	42	34202	66	
Preset Down	NEC	856A	FA	34154	250	
Preset Up	NEC	856A	8F	34154	143	
Program	NEC	859A	55	34202	85	
Random	NEC	859A	5A	34202	90	
Repeat	NEC	859A	57	34202	87	
Return	NEC	859A	67	34202	103	
Setup	NEC	856A	3E	34154	62	
Skip/Scan Back	NEC	859A	E1	34202	225	
Skip/Scan Forward	NEC	859A	E0	34202	224	
Sleep	NEC	856A	9B	34154	155	
Slow Backward	NEC	859A	6A	34202	106	
Slow Forward	NEC	859A	5B	34202	91	
Stop	NEC	859A	44	34202	68	
Sub Volume Down	NEC	856A	33	34154	51	
Sub Volume Up	NEC	856A	32	34154	50	
Surround mode	NEC	856A	2D	34154	45	
Surround Volume Down	NEC	856A	A3	34154	163	
Surround Volume Up	NEC	856A	A2	34154	162	
Test	NEC	856A	EF	34154	239	
Title	NEC	859A	64	34202	100	
Tone	NEC	856A	98	34154	152	
Tune Down	NEC	856A	EE	34154	238	
Tune Up	NEC	856A	ED	34154	237	
Tuner Digit 0	NEC	856A	89	34154	137	
Tuner Digit 1	NEC	856A	80	34154	128	
Tuner Digit 2	NEC	856A	81	34154	129	
Tuner Digit 3	NEC	856A	82	34154	130	
Tuner Digit 4	NEC	856A	83	34154	131	
Tuner Digit 5	NEC	856A	84	34154	132	
Tuner Digit 6	NEC	856A	85	34154	133	
Tuner Digit 7	NEC	856A	86	34154	134	
Tuner Digit 8	NEC	856A	87	34154	135	
Tuner Digit 9	NEC	856A	88	34154	136	
Tuner Mode	NEC	856A	6A	34154	106	
VCR/MP	NEC	856A	26	34154	38	
Volume Down	NEC	856A	9E	34154	158	
Volume Up	NEC	856A	9F	34154	159	
Zoom	NEC	859A	54	34202	84	