



M50 USB SOFTWARE UPGRADE PROCEDURE

MODEL NUMBER	M50
REFERENCE NUMBER	TD2014-12
DATE	9 April 2014

UPGRADE PROCEDURE

1. Download and unzip the [M50_usb_stick "version #".zipfile](#) and extract the file M50.IMG to a USB stick that doesn't contain any sub folders and place the IMG file directly into the root directory of the USB stick. **Please note;** The USB stick must be formatted as a FAT 32 drive.
 - a. You are not required to connect the M50 to a network to perform this upgrade.
2. Turn off the M50 unit using the back panel switch.
3. Insert the USB stick into the front USB input of the M50 unit.
4. While pressing and holding the front Power button, Turn On the M50 unit by using the back panel switch.
5. Release the front Power button once the LED begins to blink.
6. The device will then start copying the IMG file and update the firmware.
7. Once completed, the unit should reboot on its own and return to normal functionality, remove the USB stick.

HOW TO CHECK THE SOFTWARE VERSION

- Press the Menu button on the front panel of the M50. Select the Info tab to display information about the current software version, IP address and unique Internet MAC identifier.

HOW TO RESTORE M50 TO FACTORY DEFAULT SETTINGS

- Press the Menu button on the front panel of the M50. Select the factory reset tab for the below choices
 - **Yes:** Restore your M50 to its factory default settings.
 - **No:** Do not initiate factory reset.