



Internet Update Guidelines



SETUP REQUIREMENT

- Go to the C 658 product page at www.nadelectronics.com and download the corresponding owner's manual.
- Refer to the "QUICK SETUP GUIDE" section in the owner's manual for wired or wireless setup connection.

IMPORTANT!


- For wired or wireless connection to be established, ensure that a broadband router that supports Ethernet and/or Wi-Fi standard is setup and available.
- During upgrade process, the front panel display will appear inactive or have no display - this is normal. Do not interfere and let the upgrade process run its course.
- The new firmware update may be applicable only for one section. For example, if the firmware update is applicable only to MCU, then only MCU firmware details will reflect changes.
- Firmware version details shown are for reference only.
- This Internet Update Guideline is subject to change without notice. Check the C 658 product page for the latest Internet Update Guideline.

HOW TO INITIATE INTERNET UPDATE


With wired or wireless connection firmly established and the C 658 at operating mode, press \vee , \triangleright or **ENTER** front panel controls or corresponding remote control keys. **Select highlighted items.**

UPGRADE AVAILABLE


1 \vee




2 \triangleright , \triangleright




3 \vee



4 ENTER



5 ENTER



6 Internet update will proceed automatically. No further action is required. Firmware upgrade process or status is reflected in the front panel display.

7 Internet update is completed when your unit is rebooted and default or previous display is shown again.




Internet Update Guidelines




CHECK FIRMWARE DETAILS

First time inquiry of firmware version details may take a few minutes for information to be updated.


1 ▾



2 >>



3 ▾



4 >>

